

Hanging Instructions NESCHEN performance wallpaper

Wall surface and wall surface preparation

According to the technical guidelines for wallpapering and pasting work the surface to be covered must be dry, sound, uniformly absorbent, clean and smooth.

Remove old wallpaper and any unsound coatings completely. Close any holes or irregularities with plaster-based filler, such as Metylan GI smoothing and filling compound for indoors, and smooth the surface. In order to make absorbency consistent and reinforce old plaster surfaces or new plasterboard surfaces, prime the surface with water-based plaster sealer such as Metylan wallpapering primer for old plaster and concrete. Prime new gypsum plaster and firm, highly absorbent surfaces with diluted wallpaper paste. If the surface is smooth but not absorbent, you can make the surface compatible with wallpaper by applying a nonwoven liner with Metylan Ovalit V special-purpose wallcovering paste.

Paste and hanging:

For paperhanging we recommend using solvent-free non-woven glue, like Metylan NP Power Granulat plus or Metylan segura. The brand names in Europe could vary. (see list on page 2+3)

For paperhanging on the wall: Apply the wallpaper paste evenly in a sufficient amount to the base surface and lay the cut lengths of wallpaper dry into the bed of adhesive. Please read the adhesive manufacturer's instructions for use.

Using a pasting machine: Paste solvoprint performance wallpaper using a pasting machine, fold it and hang it immediately without allowing for a soaking time. Use non-woven adhesives in the way of manufacturer recommendations. Please read the manufacturer's wallpaper glue instructions.

Hang NESCHEN performance wallpaper perpendicular, with the lengths butt jointed to each other. Before start paperhanging on the wall is to ensure, that the printed surface/ink are cured and dried. Basically, a vertical paperhanging on the wall "away from light" is recommended. For prints with clean cut edges, the edge of one strip is butted up against the edge of the adjoining strip. Please note, after printing of the length of wallpaper, approx. 0,3% warping would be expected.

For overlapping printed wallpaper strips, cut off the white edges up to the pattern when the wallpaper is dry. Then align the stripes on the wall in the area where they overlap and press down with a rubber roller or a soft brush, to remove any air bubbles. On each drop, the final sweep with the rubber roller should be applied horizontally in the direction of the free edge (working direction). If a double seam cut is necessary, it will be possible to use the special-purpose knife. For a clean seam, cut through the two layers of overlapping wallpaper in one cut, remove the wallpaper adhesive residues and finish off with a seam roller. Press excess wallpaper on ceilings, skirting boards, windows etc. into the corners with a plastic trowel and trim with a Stanley knife. Ensure the wall covering does not overlap. Immediately remove any traces of adhesive on the surface with a soft, slightly damp cloth.

NESCHEN performance wallpaper are extremely hard-wearing. For heavily used environments such as catering establishments, swimming pools or event venues, we recommend coating the wallpaper after hanging with a high-quality clear varnish (e.g. Capaplex by Caparol) to protect the print.

Note: Please don't use dispersion adhesive, because a negative influence for the printed surface is to be expected! We recommend the use of protective gloves (soft cotton) when wallpapering, to protect the high-density inks. Prevent any emerging paste from getting onto the front or else stains and differences in gloss may occur. If paste does get onto the front of the paper, remove it immediately with a clean cloth and clean water.

A golden rule when wallpapering is to avoid heating the room too much and prevent draughts during the drying process or else seams may open. This information only consists of general recommendations. Working conditions and wall surface conditions are beyond our influence so no claims can be based on the information. In case of doubt you are advised to conduct your own tests beforehand.

	Metylan normal	Metylan special	Metylan direct	Metylan direct control	Metylan TG instant	Metylan NP
Germany	Metylan normal	Metylan Spezial	Metylan direct	Metylan direct control	Metylan TG Pulver	Metylan NP Neuputzkleister
Austria	Metylan normal	Metylan Spezial	Metylan direct	Metylan direct control	Metylan TG Pulver	Metylan NP Neuputzkleister
Switzerland	Metylan normal	Metylan Spezial	Metylan direct	–	–	Metylan NP Neuputzkleister
Benelux	Perfax metyl	Perfax Metyl Speciaal	Perfax Roll On	Perfax Roll On magic	Perfax Direct Klaar	Glasweefsellijs in poedervorm
France	–	Metylan Spécial	Metylan Ultra	–	–	Metylan Ovalit TDV
Spain	Metylan universal	Metylan Spezial	≈ Metylan instant	–	–	–
Portugal	Metylan universal	Metylan Spezial	≈ Metylan instant	–	–	–
Italy	Metylan universal	Metylan Spezial	≈ Metylan instant	–	–	–
Nordic	–	–	–	Pattex direct control	–	–

	Metylan TG Granulate	Metylan NP Granulate	Metylan Liquid concentrate
Germany	Metylan TG Power Granulate plus	Metylan NP Power Granulate plus	Metylan Flüssig-Kleister Konzentrat
Austria	Metylan TG Power Granulate plus	Metylan NP Power Granulate plus	Metylan Flüssig-Kleister Konzentrat
Switzerland	Metylan TG Power Granulate plus	Metylan NP Power Granulate plus	–
Benelux	Perfax Expert Vlies & Vinyl Behanglijm	Perfax Expert Glasweefsellijs	Perfax Mix&Roll Behanglijm
France	Metylan Expert	Metylan Expert Granulés Toiles de verre	Metylan Max Liquide
Spain	–	–	Metylan Liquid concentrate
Portugal	–	–	Metylan Liquid concentrate
Italy	–	–	–
Nordic	–	–	Pattex Flytande/Flydende/Flytende Konzentrat, Nestemäinen tapettiliisteritiiviste

	Metylan Ovalit V	Metylan Ovalit TM	Metylan Ovalit B	Metylan Ovalit B (brush bottle)	Metylan Ovalit Ultra	Metylan Ovalit VB
Germany	–	Metylan Ovalit TM	Metylan Ovalit B	Metylan Bordüren / Frises et Sitckers	Metylan Ovalit B	Metylan Ovalit VB
Austria	–	Metylan Ovalit TM	Metylan Ovalit B	Metylan Bordüren / Frises et Sitckers	Metylan Ovalit B	Metylan Ovalit VB
Switzerland	–	Metylan Ovalit TM	Metylan Ovalit B	–	Metylan Ovalit B	Metylan Ovalit VB
Benelux	Perfax Ready & Roll Glasweefsel	Perfax Wandlijm voor vinyl en textiel	Perfax Randenlijm	Perfax Wandlijm voor behangranden	Perfax Randenlijm	–
France	Metylan Ovalit V	Metylan Ovalit TM	Metylan Ovalit B / Frises	Metylan Bordüren / Frises et Sitckers	Metylan Ovalit Ultra	–
Spain	–	Metylan Ovalit	–	Metylan Cenefas	–	–
Portugal	–	Metylan Ovalit	–	Metylan Cenefas	–	–
Italy	–	Metylan Ovalit	–	Metylan Border	–	–
Nordic	–	–	–	–	–	–

Poland Metylan Ovalit T - Extra - Klej do nietypowych zastosowań
Hungary Metylan Ovalit T - Üvegszövet- és textiltapéta ragasztó
Russia Metylan Ovalit T

United Kingdom - comparable to - Metylan Ovalit TM= Solvite Ready to Roll Specialist Wallcoverings Adhesive

	Metylan Seam & Repair	Metylan Ovalit F	Metylan Ovalit P	Metylan Ovalit S
Germany	Metylan Naht und Reparaturkleber	Thomsit K188e	Metylan Ovalit P	Metylan Ovalit S
Austria	Metylan Naht und Reparaturkleber	Thomsit K188e	Metylan Ovalit P	Metylan Ovalit S
Switzerland	Metylan Naht und Reparaturkleber	Thomsit K188e	Metylan Ovalit P	Metylan Ovalit S
Benelux	Perfax Behangnadenlijm	–	Perfax Lijm voor muurrenovatie en polystyreen	Perfax Universele wandlijm
France	Metylan 2en1 Retouch'Express	Metylan Ovalit F	Metylan Ovalit P	Metylan Ovalit S
Spain	–	–	–	Metylan Saxit
Portugal	–	–	–	Metylan Saxit
Italy	–	–	Metylan Isolit	Metylan Saxit
Nordic	–	–	–	–